

Nozzle Diesel common rail injector parts

CR parts

DLLA152P2656 Diesel Injector Nozzle Technical Info

Content

| 1. DLLA152P2656 Diesel Injector Nozzle Introduction | 3 |
|--|----|
| 1.1. DLLA152P2656 Diesel Injector Nozzle Basic Information | 3 |
| 1.2. DLLA152P2656 Diesel Injector Nozzle Common Written Part Number | 3 |
| 1.3. DLLA152P2656 Diesel Injector Nozzle Application Information for Injectors | |
| 1.4. DLLA152P2656 Diesel Injector Nozzle Specifications and Dimensions Parameters | |
| 1.5. DLLA152P2656 Injector Nozzle Quality Control | |
| 1.6. DLLA152P2656 Diesel Injector Nozzle Customized Service | 4 |
| 1.7. DLLA152P2656 Diesel Injector Nozzle Packing List | 5 |
| 1.8. DLLA152P2656 Diesel Injector Nozzle Warranty Instructions | 6 |
| 1.9. DLLA152P2656 Diesel Injector Nozzle Manufacturer | |
| 2. DLLA152P2656 Diesel Injector Nozzle Technical Support | 7 |
| 2.1. DLLA152P2656 Diesel Injector Nozzle Installation Precautions | 7 |
| 2.2. DLLA152P2656 Injector Nozzle Inspection. | |
| 2.3. DLLA152P2656 Injector Nozzle Test Measurement | 8 |
| 2.4. DLLA152P2656 Diesel Injector Nozzle Installation | 8 |
| 2.5. DLLA152P2656 Injector Nozzle Testing After Maintenance | 9 |
| 2.6. DLLA152P2656 Injector Nozzle List of Tools Used During Measurement and Installation | 10 |
| 2.7. DLLA152P2656 Injector Nozzle Causes of Damage | 11 |
| 2.8. DLLA152P2656 Injector Nozzle Technical Support Obtaining Methods | |
| 3. DLLA152P2656 Diesel Injector Nozzle Purchase and Delivery | 11 |
| 3.1. DLLA152P2656 Diesel Injector Nozzle Purchase Payment Methods | |
| 3.2. DLLA152P2656 Diesel Injector Nozzle Main Sales Market | 11 |
| 3.3. DLLA152P2656 Diesel Injector Nozzle Declaration Requirements | 11 |
| 3.4. DLLA152P2656 Diesel Injector Nozzle Shipping Ways | 12 |
| 3.5. DLLA152P2656 Diesel Injector Nozzle Lead Time | 12 |
| 3.6. DLLA152P2656 Diesel Injector Nozzle Logistics Time for Destination Out of China's Areas | |
| 3.7. DLLA152P2656 Diesel Injector Nozzle Packing | 13 |
| 4. DLLA152P2656 Diesel Injector Nozzle Storage Standard | 14 |
| 5.Company Information | 14 |
| 5.1. Company Introduction | 15 |
| 5.2. Contact Information | 15 |
| 6. Copyright Policy | 15 |

DLLA152P2656 Diesel Injector Nozzle Technical Info

1. DLLA152P2656 Diesel Injector Nozzle Introduction

Mechanical diesel injector nozzle works by controlling precision couplings (needle valve, needle valve body). The coupling of the nozzle is one of the three precision (Three precision coupling parts include plunger, plunger sleeve, needle valve, needle valve body, oil outlet valve, oil outlet valve seat) couplings of the traditional diesel engine.

Normally, The injector nozzle itself is a closed valve, The opening and closing of the valve is controlled by a valve needle moving up and down. When the ECU issues a fuel injection command, its voltage signal will cause current to flow through the coil in the fuel injector nozzle, generating a magnetic field to attract the valve needle, allowing the valve to open so that fuel can be sprayed out from the fuel injection hole.

The biggest advantage of injection fuel supply is that the control of fuel supply is very precise, so that the engine can have the correct air-fuel ratio in any state, not only to keep the engine running smoothly, but also the exhaust gas can meet the environmental protection regulations.

1.1. DLLA152P2656 Diesel Injector Nozzle Basic Information

| Title | Common Rail Diesel Injector Nozzle DLLA152P2656 | Quality |
|-------|---|----------------|
| Sku1 | G1L1LA152P2656 | China made new |
| Sku2 | G1S8LA152P2656 | China made new |
| Sku3 | G1X9LA152P2656 | XINGMA |
| Sku4 | G1HX16A152P2656 | Shumatt |
| Sku5 | G1Z17LA152P2656 | LIWEI |

1.2. DLLA152P2656 Diesel Injector Nozzle Common Written Part Number

| Injector Nozzle Order Number | Injector Nozzle Engraved Number |
|------------------------------|---------------------------------|
| 0433172656 | DLLA152P2656 |

1.3. DLLA152P2656 Diesel Injector Nozzle Application Information for Injectors 1) DLLA152P2656 Diesel Injector Nozzle Application for Injectors Part Number

| Injector Part Number | Injector Series | System Pressure | Re-manufactured Part Number | System Pressure |
|-------------------------|---|------------------|--------------------------------|-----------------|
| | $\sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{j=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{j=1}^{n} \sum_{j=1}^{n} \sum_{j=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{j$ | $\sum_{i=1}^{n}$ | $\sum_{i=1}^{n}$ | |

2) DLLA152P2656 Diesel Injector Nozzle Car Model Matching Information

| Injector Part Number | Car Number | OE Number | OE Number | OE Number | |
|-------------------------|------------|-----------|-----------|-----------|--|
| | | | | | |

DiN

3) DLLA152P2656 Injector Nozzle Part Number Common Writing

0433172656,DLLA152P2656,0 433 172 656,DLLA 152 P 2656,0433 172 656,DLLA152 P 2656, 0433172 656,DLLA152P 2656,0 433 172656,DLLA152 P2656,0 433172656,DLLA 152P2656, 0 433172 656,DLLA 152P 2656

1.4. DLLA152P2656 Diesel Injector Nozzle Specifications and Dimensions Parameters

Injector Nozzle Size: 6 cm*1.5cm *1.5 cm

Injector Nozzle Barrel Dimensions: 7 cm *2 cm *2 cm

Single Injector Nozzle Weight: 0.03kg

Injector Nozzle 10 PCS Per Box: 10 cm *8 cm *4cm

Injector Nozzle Weight 10 PCS Per Box : 0.3kg

Injector Nozzle Quality: China Made New Injector Nozzle

Injector Nozzle MOQ: 10 PCS

1.5. DLLA152P2656 Injector Nozzle Quality Control

1) Injector Nozzle Testing

All parts of the injector nozzle are subjected to precision testing, high temperature testing, low temperature testing, withstand pressure testing, leakage testing, durability testing, and various working conditions testing.

2) Injector Nozzle Inspection

The factory inspection of the injector nozzle is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same injector nozzle for a total of no less than three times for factory inspection, and the fuel injector installation testing environment are progressed in dust-free workshop.

3) Injector Nozzle Installation


When matching the valve cap and valve steam, Shumatt strictly complies with the standard of valve cap and valve stem clearance technical indicators to ensure that each valve assembly meets the factory standards and use standards.

1.6. DLLA152P2656 Diesel Injector Nozzle Customized Service

1) Diesel Injector Nozzle Customized Service: The quantity of customized item must meet the demands of OEM manufacturers' requirement for shell lettering (such as logo, nozzle part number, date and series number), nozzle without lettering, nozzle tube, nozzle box etc.

2) Diesel Injector Nozzle Customized Items





Injector Nozzle Without lettering



3) Diesel Injector Nozzle Customized Service Quantity Requirements:

• The purchased of customized diesel injector nozzle shell lettering or without lettering are no less than 100 pieces.

• The purchased of customized injector nozzle tubes are no less than 2000-3000 pieces.

• The purchased of customized injector nozzle boxes are no less than 1000 pieces.

• Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

• Once the customized injector nozzle is sold, it can't be returned or exchanged if there is no quality problems.

1.7. DLLA152P2656 Diesel Injector Nozzle Packing List

1) Diesel Injector Nozzle Spare Parts List

| No. | $), \cup, \cup, \cup, \cup, \cup$ | |
|-------------|---|---|
| | | |
| Image | | |
| Name | Injector Nozzle Assy | Nozzle Tube |
| Description | Injector Nozzle Part Number DLLA152P2656 | Prevent Nozzle Rusting and Damaging from Collision |



| No. | 3 | 4 | |
|-------------------|--|---|--|
| Image | | Common Rail Injector Nozzle Iso 9001:2008 Certified © CPIC Accept Insurance 10Pcs | |
| Name | Nozzle Tube | Liwei Injector Nozzle Box | |
| Description | Prevent Nozzle Rusting and Damaging from Collision 10 PCS/Box | | |
| No. | | | |
| Image | 大轨喷油嘴 Common Rail Injector Nozzle (東西里, 日平天下 兴马共轨 | | |
| Name | Xingma Injector Nozzle Box | $\mathcal{O}(\mathcal{O}(\mathcal{O}))$ | |
| Description | 10 PCS/Box / | | |
| A Minors a | re prohibited to use fuel injector nozzle assem | bly pozzle packing boy to avoid injury | |

Minors are prohibited to use fuel injector nozzle assembly, nozzle packing box to avoid injury.
A Leister and here is a soluble and any here any here and any here any here.

▲ Injector nozzle box is recyclable and can be reused。

lacksquare Injector nozzle barrels is non-degradable material, please dispose of it properly after use.

1.8. DLLA152P2656 Diesel Injector Nozzle Warranty Instructions

1) Diesel Injector Nozzle Warranty Conditions and Instructions

• It is necessary to provide pictures, videos, or test reports detected by the injector nozzle inspection equipment when the injector nozzle is abnormal during use as evidence to feed back to the salesman.

• Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

2) Injector Nozzle Warranty Coverage

• Within 15 days after customer receives the DLLA152P2656 injector nozzle if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

• If the DLLA152P2656 injector nozzle has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

• If the injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

3) Injector Nozzle Out of Warranty Coverage

• The warranty period has expired.

• Injector nozzle failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali

DiN

land, earthquake, and used in abnormal environment.

• Injector nozzle damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).

• Injector nozzle failure or injector damage caused by non-injector design, technology, manufacturing, quality and other issues.

- Injector nozzle failure due to system pressure exceeding system approved pressure.
- Injector nozzle failure caused by system voltage exceeding approved voltage.

• Injector nozzle failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.

• Injector nozzle failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).

• Injector nozzle failure caused by not following the installation angle specified in the injector maintenance manual.

• Injector nozzle failure caused by not following the cleaning requirements specified in the injector maintenance maintenance manual.

• Injector nozzle failure caused by failure to replace consumable parts as specified in the injector maintenance manual.

1.9. DLLA152P2656 Diesel Injector Nozzle Manufacturer

Diesel Injector Nozzle manufacturer: Shenzhen Shumatt Technology Co., Ltd

2. DLLA152P2656 Diesel Injector Nozzle Technical Support

2.1. DLLA152P2656 Diesel Injector Nozzle Installation Precautions

- 1) Clean the injector nozzle in an ultrasonic cleaner for 3-5 minutes before installation, so as to make the stains, dust, rust-proof oil oxides, paraffin base, naphthenic base, intermediate base, salt, lead naphthenate, zinc naphthenate, sodium petroleum sulfonate, barium petroleum sulfonate, calcium petroleum sulfonate, tallow diamine trioleate, rosinamine on the surface of the injector nozzle fall off.
- **2)** Use compressed air to clean the cleaning fluid attached to the surface of the injector nozzle after cleaning, and clean it up to the standard of use.

2.2. DLLA152P2656 Injector Nozzle Inspection.

1) Check whether there is deformation, cracking, thread damage, quenching, leakage and rust in the guide sleeve, spring, gasket and tight cap of the nozzle. The tight cap of the nozzle must be replaced after being disassembled for more than 5 times, as shown in the following.



2) Replace the tight cap of the nozzle and the copper gasket of the injector nozzle

DiN

- **3)** Check whether the gap between the nozzle needle and the nozzle shell is within the standard range and whether it reaches the standard for use
- All parts should be examined for wear under a microscope at least 20 times larger
- Nozzle tight cap deformation, cracking, thread damage, quenching, leakage, will lead to black smoke vehicle cap, fuel injector damage.
- ▲ Injector opening pressure greater than or less than the specified range may cause injector damage.
- A Failure to replace wearing parts in time during maintenance may lead to fuel injector damage.

2.3. DLLA152P2656 Injector Nozzle Test Measurement

1) Nozzle opening pressure test

Test whether the opening pressure range of the nozzle is within the range specified in the injector maintenance manual (to be verified), if not within the normal range, adjust the nozzle spring to adjust the gasket

▲ If the value is greater than normal, reduce the oil nozzle spring adjusting gasket; if the value is less than normal, increase the oil nozzle spring adjusting gasket.

2) Stroke Measurement of Nozzle Needle Valve

Use a measuring tool to measure whether the stroke of the nozzle needle valve is within the range (15-45um) specified in the injector maintenance manual. If not, adjust the stroke of the nozzle to adjust the gasket.



▲ If the value is greater than normal, thicken the gasket for oil-nozzle needle valve lift adjustment; if the value is less than normal, reduce the gasket for oil-nozzle needle valve lift adjustment

2.4. DLLA152P2656 Diesel Injector Nozzle Installation

1) Tightening torque of injector nozzle

The torque lever and tightening moment specified in the injector maintenance manual must be installed when the injector nozzle is installed. (50Nm)



• The tightening torque of the nozzle cap must be installed in accordance with the tightening torque specified in the injector maintenance manual

2.5. DLLA152P2656 Injector Nozzle Testing After Maintenance

1) After installation, it needs to be tested on the test bench.



The correct injector type should be selected for testing

The test results need to be ensured that the following items are within the standard data range of the 2) test stand.

LEAK TEST: Test whether sealing test is up to standard or not

In this step, no injector collector should be installed at the nozzle during the test so as to observe whether the nozzle is dripping oil, meanwhile observe that all joints are no oil leaking.

The static oil return of the test should not exceed 8mm2/H, otherwise, you need to check whether the high-pressure sealing ring, valve assembly, and stroke parameters of the injector are within the standard range.

VL: Test whether full load oil (main injection, high speed) is up to standard or not

This step needs to be combined with vehicle driving conditions, such as power, fuel consumption and smoke as well as the maintenance of the engine, if there is situation of insufficient power, fuel consumption is high, thick black smoke and irregularly maintenance of the engine, the engine needs to be maintained according to the maintenance handbook at very first time.

• Each of injector part needs to be adjusted and checked if there is any damage according to above situations to ensure the injector is normal. After make sure the injector works normal, you need to reduce the armature stroke if too much oil injection, and increase the armature stroke if too little oil injection.

The error of each injector should be controlled in 6mm3/HH when adjusting.

TL\EM: Test whether the torque point, emission point, exhaust limit, fuel supply reach standard or not

Through this test, it is detected that when the oil injection is too little, the engine's acceleration is slow, vice versa, when the oil injection is too much, the engine's acceleration will produce black smoke and the engine excessive exhaust emissions.

• Injector nozzle spring force gasket, armature stroke, lift gasket and solenoid valve spring force gasket determine whether exhaust restriction and injector fuel supply reach standard

LL: Test if the idle fuel supply reaches the standard

This test detects oil injection is too much will cause engine idle smoke, otherwise if the oil injection too little will cause engine idling easy to stall, or difficult to start.

• The uneven of oil injection causes the unstable rotation speed of engine , making noise, and increase the engine swing in the acceleration process.

• Each injector error should be controlled within 2mm3/HH when adjusting.



• Idle speed fuel supply quantity mainly by adjusting the nozzle spring force gasket.

VE: Test whether the pre-injection meets the standard

• This test detects when oil injection is too much will cause cylinder knocking while the engine is working and the exhaust emissions is not up to standard (smoke).

• While when oil injection is too little will cause big noise while the engine is working, the engine is difficult to start, the engine weak acceleration, slow response of injector.

• Each injector error should be controlled within 0.5mm3/HH when adjusting.

2.6. DLLA152P2656 Injector Nozzle List of Tools Used During Measurement and Installation

| Image | shun tt | |
|---|---|--|
| SKU | CRT084 | CRT220 |
| Description | Torque wrench: 19-110nm 1/2 It is used to control tightening force and angle during installation | Fuel injector stroke measuring tool: is used to measure buffer stroke of fuel injector, armature stroke and remaining air gap |
| Image | shumati | |
| SKU | CRT079 | |
| Description | Micrometer: is used to measure gasket thickness | Ultrasonic cleaning machine: is used for cleaning fuel injector and parts |
| Image | | |
| SKU | CRT281 | |
| $\gamma \gamma $ | | |

© 2023 Shenzhen Shumatt Technology Co., Ltd

www.dieselinjectornozzles.com

| | Common rail injector test | |
|-------------|---|----|
| Description | bench: check the injector working condition | .(|

2.7. DLLA152P2656 Injector Nozzle Causes of Damage

- **1)** Fuel injector nozzle failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in fuel exceeding standard requirements.
- 2) The nozzle is normally worn due to long time working under high temperature
- 3) Nozzle needle wear leads to oil hole blockage, insufficient fuel injection injector cannot work properly.
- A Nozzle needle wear leads to oil hole blockage, insufficient fuel injection injector can't work properly.

A The wear of the nozzle leads to the increase of fuel quantity, resulting in black smoke of the vehicle, and the fuel injector can't work properly when it is serious.

A If the nozzle needle can't move smoothly stuck may cause serious damage to the injector nozzle

A The rusting of the nozzle spring leads to spring fracture and black smoke from the vehicle.

▲ The opening pressure of the nozzle decreases, and the oil quantity of the injector increases, leading to black smoke of the vehicle, and the injector can't work properly when it is serious.

• Oil-nozzle needle valve lift adjustment gasket wear oil-nozzle needle valve stroke becomes larger, the fuel injector oil quantity becomes larger, resulting in black smoke of vehicles, resulting in the fuel injector can't work properly when serious.

A The cracking of the nozzle cap is caused by high intensity work under high temperature.

2.8. DLLA152P2656 Injector Nozzle Technical Support Obtaining Methods

- 1) Injector Nozzle Technical File, visit <u>http://shumatt.com</u> to get the technical file
- 2) Injector Technical Videos

Facebook: Visit <u>https://www.facebook.com/hison.li</u> constantly follow can get more information.

YouTube: Visit <u>https://www.youtube.com/channel/UCByvYBx7VjV_mAfxh_Hu-aw</u> to get the technical videos, and can learn more information if you follow .

Shumatt: Visit <u>http://shumatt.com</u> to get the technical videos.

3) Injector Nozzle Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit <u>http://shumatt.com</u> to get the download and installation tutorial

4) Search The injector nozzle test data through TruckBook Parts EPC APP.

3. DLLA152P2656 Diesel Injector Nozzle Purchase and Delivery.

3.1. DLLA152P2656 Diesel Injector Nozzle Purchase Payment Methods

Payment Methods: T/T, PayPal, Alipay, WeChat

Please contact our salesmen for specific payment information.

3.2. DLLA152P2656 Diesel Injector Nozzle Main Sales Market.

Diesel Injector Nozzle Main Sales Markets: Asia, Europe, North America, South America, Africa etc.

3.3. DLLA152P2656 Diesel Injector Nozzle Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance:

contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. DLLA152P2656 Diesel Injector Nozzle Shipping Ways

Destination in China areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations out of China's areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. DLLA152P2656 Diesel Injector Nozzle Lead Time

Lead time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases) .

3.6. DLLA152P2656 Diesel Injector Nozzle Logistics Time for Destination Out of China's Areas DHL Logistics Time:

| Country or Region of Departure | Hong Kong, China | Other Countries or Regions of Asia | Australia and New Zealand | Europe | America | Other Countries |
|-----------------------------------|---------------------|---------------------------------------|------------------------------|--------|---------------|--------------------|
| China's Mainland | 7 Days | 7 Days | 8 Days | 8 Days | 8- 12 Days | 7-10 Days |

UPS Logistics Time: Country or Region of Departure: China's Mainland

| Country of Destination | Estimated Arrival Time | Country of Destination | Estimated Arrival Time | Country of Destination | Estimated Arrival Time |
|---------------------------|---------------------------|------------------------|---------------------------|------------------------|---------------------------|
| Japan | 3 Days | UK | 5-7 Days | Egypt | 5-7 Days |
| Turkey | 5-7 Days | Singapore | 3 Days | Switzerland | 5-7 Days |
| Bahrain | 5-7 Days | Latvia | 7-10 Days | New Zealand | 7-10 Days |
| Sri Lanka | 5-7 Days | Thailand | 3 Days | Austria | 5-7 Days |
| Romania | 5-7 Days | Vietnam | 3-5 Days | Estonia | 5-7 Days |
| Malaysia | 3-5 Days | Israel | 5-7 Days | Mexico | 7-10 Days |
| France | 5-7 Days | America | 5-7 Days | United Arab Emirates | 5-7 Days |
| Italy | 5-7 Days | Netherlands | 5-7 Days | Bengal | 7-10 Days |
| Lebanon | 5-7 Days | Philippine | 3-5 Days | Greece | 7-10 Days |
| South Korea | 3 Days | Spain | 5-7 Days | Myanmar | 5-7 Days |
| Canada | 5-7 Days | Germany | 5-7 Days | Saudi Arabia | 7-10 Days |
| Portugal | 5-7 Days | Australia | 5-7 Days | South Africa | 7-10 Days |
| Denmark | 5-7 Days | Belgium | 5-7 Days | Ukraine | 7-10 Days |
| India | 7-10 Days | Qatar | 7-10 Days | Poland | 5-7 Days |
| Indonesia | 3-5 Days | Morocco | 7-10 Days | Pakistan | 7-10 Days |
| Kuwait | 7-10 Days | | | in the state | |

The logistics time is for reference only, subjects are according to the actual arrival.


3.7. DLLA152P2656 Diesel Injector Nozzle Packing

Domestic express packaging: Usually wrapped in waterproof scotch tape, such as picture No.2.





International express packaging: Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 3.





Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 4,



Pic No.4

A The products can be packaged according to customers' requirements.

The packing tray is made of plastic and can be recycled.
Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.

4. DLLA152P2656 Diesel Injector Nozzle Storage Standard

1) Choose a suitable storage place

The warehouse and cargo yard where the injector nozzles are stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

2) Strict requirements of warehousing

Strict inspections should be carried out when the injector nozzles are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged nozzles must be protected from damage.

3) Keep the warehouse dry and preventing moisture

The relative humidity is usually below 70% for the injector nozzles placed in the room, and the corrosion of the injector nozzles is significantly reduced.

Injector nozzles must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

4) Stack Properly

After the injector nozzle is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse


If the injector nozzle package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

A It is forbidden to leave the injector nozzle exposed in the air for a long time.

A It is forbidden to store acid, alkali, salt and other substances together with the injector nozzle.

A The unpacked diesel injector nozzle must be rust-proof during secondary storage.

5.Company Information



Global Exhibitions

5.1. Company Introduction

Chinese Name: 深圳市舒马特科技有限公司

English Name: Shenzhen Shumatt Technology Co., Ltd

Mob Phone/WeChat: +86-13410541523

HK Telephone: +852-67653519

Telephone: +86-755-23215133

Email: <u>ruby@shumatt.com</u> Website: www.shumatt.net

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

Shenzhen Office: Room 428-430, Building B, Huafeng Zhigu Technology Industrial Park, Exit B, Fuyong Metro Station, Bao'an District, Shenzhen, China's Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: <u>1.8. DLLA152P2656 Diesel Injector Nozzle Warranty Instructions</u>)

5.2. Contact Information

| Name | WeChat/ WhatsApp | Email |
|------|------------------|-------------------|
| Ruby | +86-13410541523 | hison@shumatt.com |

6. Copyright Policy

All the content in this file "*DLLA152P2656 Diesel Injector Nozzle Technical Info*", including text, pictures, web page layout design, logo, label etc. are belong to Shenzhen Shumatt Technology Co., Ltd.

Visitors may use the content or services provided by this website (www.dieselinjectornozzles.com) for personal study, research or appreciation, and other non-commercial or non-profit purposes, but at the same time, they shall abide by the provisions of copyright law and other relevant laws, and shall not infringe upon this website and related legal rights of the obligee.

In addition, when using any content or services of this file "*DLLA152P2656 Diesel Injector Nozzle Technical Info*" for other purposes, written permission from this website and Shenzhen Shumatt Technology Co., Ltd is required. Any other questions to use this file, please contact us through hison@shumatt.com.